

MSR Bracket Installation Guide

This guide is designed to help you efficiently assemble a 15 inch Vesa Mount LCD with a UTC RETAIL MSR Bracket.

Components:

You will find the following components inside the MSR Box:

- MSR with Bracket Assembled
- Four LCD Mounting Screws.

Steps:

Step 1)

Assemble the bracket using the upper two mounting screws. Only tighten the screws about 2 turns (See Figure A).



Figure A

Step 2)

Load the LCD & bracket onto an UTC RETAIL LCD Arm using the keyway holes (See Figure B).



Figure B

Step 3)

Assemble the remaining two screws and tighten all of the screws being careful not to over-tighten them. Route the cable through the channel on the LCD arm (See Figure C). The assembly is complete.




Figure C

Note: Please contact UTC RETAIL Technical Support at 800.349.0546, if you have any problems with the installation.